


Users manual/Használati útmutató

JEANIE delay



1. DC 12V power connector (centre negative, 5.5/2.5 mm). We recommend the use of the Hunor power supplies!
2. Tube socket with tube.
3. Output 6.3mm jack connector.
4. Input 6.3mm jack connector.
5. Level pot, adjust the effect level.
6. Repeat pot, adjust the number of the delayed signal.
7. Delay pot, adjust the delay time.
8. Gain pot, adjust the gain of the tube part.
9. Effect ON/OFF state indicator LED.
10. Footswitch for switching effect ON/OFF.

1. DC 12V (center negatív, 5.5/2.5mm) tápcsatlakozó.
2. Elektroncső.
3. Kimenet, 6.3mm jack csatlakozó.
4. Bemenet, 6.3mm jack csatlakozó.
5. Level potenciométer az effekt szintjének beállításához
6. Repeat potenciométer a késleltetett jel darabszámának beállításához.
7. Delay potenciométer a késleltetés idejének beállításához.
8. Gain potenciométer a csöves fokozat erősítésének beállításához.
9. Effekt BE/KI állapotjelző LED
10. Lábkapcsoló az effekt BE/KI kapcsolásához.